



# AUTO300 WIFI User Manual

Got a Question?  
Visit [www.navman.com.au/faq](http://www.navman.com.au/faq) | [www.navman.co.nz/faq](http://www.navman.co.nz/faq) for more information

Revision: R00 (03/2021)

**Trademark**  
All brand and product names are trademarks or registered trademarks of their respective companies.

**Disclaimer**  
Specifications and documents are subject to change without notice. Navman does not warrant this document is error-free. Navman assumes no liability for damage incurred directly or indirectly from errors, omissions, or discrepancies between the device and the documents.

**Note**  
Not all models are available in all regions. Depending on the specific model purchased, the colour and look of your device and accessories may not exactly match the graphics shown in this document.

**Regulatory information**  
For regulatory identification purposes, the Navman AUTO300 WIFI is assigned a model number of N606. Marking labels located on the exterior of your device indicate the regulations your model complies with. Please check the marking labels on your device and refer to the corresponding statements in this section. Some notices apply to specific models only. The user needs to switch off the device when exposed to areas with potentially explosive atmospheres such as petrol stations, chemical storage depots and blasting operations.

**WEEE**  
 This product must not be disposed of as normal household waste, in accordance with the EU directive for waste electrical and electronic equipment (WEEE – 2012/19/EU). Instead, it should be disposed of by returning it to the point of sale, or to a municipal recycling collection point.

## Formatting a card

- To format a memory card, do one of the following:
- Use the Navman MiVue Pro app to format a memory card ( > **Settings** > **Format SD Card** ).
  - On your dash cam, press the WiFi/Mute button 4 times consecutively.

**Note:**

- DO NOT apply pressure to the centre of the memory card.
- Navman does not guarantee the product's compatibility with memory cards from all manufacturers. Please check your card manufacturer's specifications and warranty to ensure it is suitable for use in dash cameras and loop recording devices.
- Before you start recording, please format the memory card via Navman MiVue Pro to avoid malfunction caused by files not created by the dash cam.
- If the REC indicator of the device glows in red, format your SD card. If the problem persists, try another SD card.
- You may need to format your memory card periodically to ensure it remains in good condition.
- You are advised to turn the device off before removing the memory card.

## Turning the dash cam on

Complete the installation according to the instructions in the "Using your dash cam in a vehicle" section. Once the vehicle engine is started, the dash cam automatically turns on.

## Shutting down the dash cam

Occasionally you may need to perform a hardware reset when the dash cam stops responding or if it appears to be "frozen" or unresponsive.


To shut down the dash cam, press and hold the Power button until the system powers off.

If the system does not shut down by keeping the Power button pressed, you can force it to shut down by inserting a pointy object (such as a straightened paper clip) into the Shutdown button of the device.

## Setting the date and time

- To make sure that the date and time of your recordings are correct, use the Navman MiVue Pro app to check the settings.
- Turn the dash cam on.
  - Launch Navman MiVue Pro on the connected smartphone.
  - Tap > **Settings** > **Date / Time**.
  - Do one of the following:
    - Select **Manual** and the system will update its date and time settings by synchronising them with the connected smartphone.
    - Select **GPS** and set the **Time Zone** and **Daylight Saving Time** options according to your location. When done, the system will set date and time automatically.

## Getting to know your dash cam



- System indicators (WIFI/REC/MUTE)
- Device mount
- Shutdown button
- Memory card slot
- Power/Event button
- WiFi/Mute button
- Microphone
- Camera lens
- Speaker
- Parking indicator
- Mini-USB connector

### Power/Event button

- When the dash cam is connected to the power source, press the button briefly to turn it on.
- When the dash cam is powered on, press the button briefly to start event recording.
- When the dash cam is powered on, press and hold the button for 5 seconds to turn it off.

### WiFi/Mute button

- Press the button briefly to mute or unmute the microphone during recording.
- Press and hold the button for 5 seconds to turn WiFi mode on or off.
- Press the button 4 times consecutively to format the SD card.

### LED indicators

#### WiFi indicator (blue)

- Glow in blue when WiFi mode is turned on.
- Flashes in blue when the dash cam is connected to a smartphone (recording is disabled under this mode).

#### REC indicator (green/red)

- Glow in green when the recording is in progress.
- Flashes in green when an event recording is in progress.
- Glow in red when there is an error with the memory card and recording has stopped.
- Flashes in red when the memory card is being formatted or an over-the-air (OTA) update is in progress.

#### MUTE indicator (amber)

- Glow in amber to indicate the microphone is muted during recording.

#### Parking indicator (white)

- Glow in white when the system enters Parking Mode.

## Recording in driving mode

### Continuous recording

The system will automatically begin continuous recording shortly after start-up. The recording may be divided into several video clips; recording will not stop between video clips. When your memory card fills up with continuous recordings in the "Normal" category, it will automatically record over the oldest existing files in this category.

### Event recording

If an event happens such as a sudden impact, high speed driving, an aggressive turn or an accidental crash during continuous recording, the G-sensor will prompt the dash cam to start recording the event. The event recording will continue for 20 seconds to save the duration from 5 seconds before the event until 15 seconds after the event. The event recording can last up to 1 minute if the sensor is triggered again while recording. When your memory card fills up with event recordings in the "Event" category, it will automatically record over the oldest existing files in this category.

If you want to manually start an event recording while continuous recording is in progress, press the Event button briefly.

**Note:** You can change the sensitivity level of the G-sensor via Navman MiVue Pro.

## Parking Mode

**Note:** The dash cam cannot operate in Parking Mode by relying on its internal battery. An additional accessory such as an uninterruptible power cable or the Smart Box is required. Please visit [www.navman.com.au/mivue-smartbox](http://www.navman.com.au/mivue-smartbox) or [www.navman.co.nz/mivue-smartbox](http://www.navman.co.nz/mivue-smartbox) for purchasing information.

Parking Mode is disabled by default. To enable the function, open Navman MiVue Pro on the connected smartphone and select > **Settings** > **Parking Mode** > **Detection** > **On**.

Whenever Parking Mode is enabled, the system will enter Parking Mode when the car stops moving for about 5 minutes. During Parking Mode monitoring, recordings can be triggered only by motion or vibration.

**Note:** The feature is triggered by the device's G-sensor and detected motion. You can change the settings via Navman MiVue Pro.

The parking recording will continue for 20 seconds to save the duration from 5 seconds before the event until 15 seconds after the event. The parking recording can last up to 1 minute if the sensor is triggered again during recording. The system will exit Parking Mode when more than 5 seconds of continuous vibration is detected (for example, when the car starts moving).

## Navman MiVue™ Pro

Navman MiVue™ Pro is a mobile app which allows you to view, share and back up videos recorded on the dash cam via WiFi. Search for "Navman MiVue Pro" in the Apple App Store or Google Play Store to download the app for free.

### Note:

- Navman MiVue Pro is compatible with iOS 9.0 (and above) and Android 5.0 (and above) devices. Navman does not guarantee the product's compatibility with smartphones from all manufacturers.
- Not all dash cam models support Navman MiVue Pro or all of its features.

## Setting up a WiFi connection

On your dash cam, press and hold the WiFi button for 5 seconds to enable WiFi mode. The WiFi indicator glows in blue when WiFi mode is enabled.

Follow the steps below to set up a WiFi connection between the dash cam and smartphone via Navman MiVue Pro.

- Make sure that you have enabled the WiFi function on the smartphone.
- Launch Navman MiVue Pro and tap the "+" icon.
- Tap **Select WiFi** and select the dash cam to connect with (SSID: MiVue\_XXXX, password: 1234567890).
- Return to Navman MiVue Pro and tap **Done** to complete the WiFi connection.

### Note:

- All screenshots and instructions related to app operation are for reference only. Actual setting options and methods may vary depending on the software version and smartphone make/model.
- If you encounter any problems while connecting the devices, reset WiFi mode on the dash cam. If the problem persists, contact Navman Customer Support or visit [www.navman.com.au](http://www.navman.com.au) / [www.navman.co.nz](http://www.navman.co.nz) for further assistance.

## Using Navman MiVue Pro


- Once the devices are connected, the screen will display the main page ( ).

- Tap **Live View** to watch the live video of the connected dash cam.
- Tap **Settings** to change the settings for the dash cam.

**Note:** The video resolution of the dash cam is set to a temporary default value whenever the dash cam is connected to a smartphone. The setting will automatically revert to its original value once the devices are disconnected.

- Tap **SD card** to access the video list to download or delete the recordings on the dash cam.
- Tap **Info** to display the information of the dash cam.
- Tap to connect a new dash cam.

- Tap to view downloaded recordings.
- Tap to change the storage location of downloaded recordings (available for Android only), update firmware, and view app information.



## System settings

Open Navman MiVue Pro on the connected smartphone and tap > **Settings** to customise system settings.

### Video Recording

- Video Clip Length:** Sets the length of each video clip for a continuous recording (1 Min., 3 Min. or 5 Min.).
- Resolution:** Sets the recording quality.
- Frequency:** Sets the frequency for the camera to avoid problems caused by artificial light sources that are not constant.
- WDR:** Enables the Wide Dynamic Range (WDR) function to improve the dash cam's image quality under high-contrast lighting conditions.
- EV:** Sets the exposure level (-1 – +1) to adjust the brightness of the image.
- G-Sensor:** Sets the sensitivity level of the G-sensor that allows automatic triggering of event recording while continuous recording is in progress.
- Stamps:** Sets the information (**Coordinates** or **G-Sensor**) that will be displayed on each recorded video.
- Speed stamp:** Displays the driving speed on each recorded video.

### Driving Safety

**Note:** Not all Navman dash cam models support all of the driving safety features listed below.

The dash cam provides advanced driving safety functions to make your driving safer.

- Calibration:** You are advised to calibrate the system constantly in order to be alerted properly. Follow the steps to calibrate the system.
  - Drive the vehicle in the middle of the lane.
  - Ask a passenger to select this option and follow the on-screen instructions to complete calibration.



- LDWS:** The system will alert you when it detects that the car speed is over 60 km/h and the car has strayed from its intended lane.
- FCWS:** The system will alert you when the car moves slowly and gets too close to the car ahead.
- Headlight Reminder:** The system will remind you to turn the lights on when driving after dark.
- Fatigue Alert:** The system will remind you to take a break during a long-distance drive (2 hours, 3 hours or 4 hours).
- Stop and GO:** The system will alert you when the car ahead has proceeded to go after being stopped for longer than 10 seconds.

### Parking Mode

- Detection:** When enabled, the dash cam will automatically enter Parking Mode when the car stops moving for about 5 minutes.
- Security LED Indicator:** Turns the parking indicator on/off during Parking Mode monitoring.

## Updating your dash cam

Occasionally, Navman may offer various software updates (such as device firmware or voice data). Updates are installed via OTA updates using Navman MiVue Pro. When an update is available, you will be prompted when launching the app. Follow on-screen instructions to download and install updates. The dash cam requires a microSD to be inserted in order to download OTA updates.


## Using your dash cam in a vehicle

### Note:

- The dash cam should be placed near the rear-view mirror to ensure optimal camera angle and video quality.
- Select an appropriate location for mounting the device in a vehicle. Never place the device where the driver's field of vision is blocked.
- If the windscreen is tinted with a reflective coating, it may be athermic and impact GPS reception. In this instance, please mount the device in a "clear area".
- The system will automatically calibrate the G-sensor during start-up. If the device's viewing angle or installation position was changed from the original position after start-up, please turn the device off and on again to recalibrate the G-sensor. Otherwise the G-sensor may malfunction and impact other features of the device (such as event-driven recording and Parking Mode).
- The dash cam is designed to stay connected with the vehicle power adapter at all times. The internal battery is designed to allow the dash cam to save the last recording in case the vehicle's power system fails during an incident. The internal battery is not the primary power source.

## Mounting the dash cam

- Make sure that your car is parked on level ground. Follow the instructions to securely mount your dash cam into a vehicle.



### Note:

- Before sticking the mounting pad, cleaning the windscreen with rubbing alcohol is recommended.
- If the adhesion of the adhesive tape does not perform well, replace the tape with a new one.

- Detection Method:** Sets the detection method (**G-Sensor**, **Motion** or **Motion & G-sensor**) to start parking recording when the system detects motion or if an event happens during Parking Mode monitoring.
  - G-Sensor Sensitivity:** Sets the sensitivity level of the G-sensor that allows automatic triggering of parking recording when the dash cam is in Parking Mode.
  - Motion Detection:** Sets the sensitivity level of motion detection to **Low**, **Medium** or **High**.
- System**
- Date / Time:** Sets the system date and time.
  - Welcome Sound:** Enables/disables the startup sound.
  - Volume:** Adjusts the volume level.
  - Distance Unit:** Sets the preferred distance unit.
  - Format SD Card:** Formats a memory card. (All data will be erased.)
  - Restore to Defaults:** Restores the system settings to the factory defaults.

## MiVue Manager

MiVue Manager is an application for viewing videos recorded by the Navman dash cam.

**Note:** Not all features are available on every model.

## Installing MiVue Manager

Download the Setup file from [www.navman.com.au/mivue-update](http://www.navman.com.au/mivue-update) or [www.navman.co.nz/mivue-update](http://www.navman.co.nz/mivue-update) for your Windows or Mac PC. Double-click Setup.exe and follow the on-screen prompts to install MiVue Manager. IMPORTANT! You may be prompted to install the MOV and AVI codecs for video playback if they are missing on your computer. Search online to install the required codecs.


## Playing the recording files

- Remove the memory card from the dash cam and access the card on the computer via a card reader; or connect the dash cam to your computer via a mini USB cable (not supplied). You are advised to copy the recording files to your computer for backup and playback.
- Start MiVue Manager on the computer.
  - By default, MiVue Manager shows the calendar and the file list on the right.
  - When a recording file exists, you will see the date marked with "•". Click that date to display the files that were recorded on that date.
  - You can choose the file type to display: **Event / Normal / Parking**.
  - To display all files in the current folder, click **All**. To return to the calendar view, click **Calendar**.

**Note:** Your model may not support all file types.

- Double-click the desired file on the file list to start playback.

- Connect the cables. Route the cable through the top ceiling and the A-pillar so that it does not interfere with driving. Make sure that the cable installation does not interfere with the vehicle's airbags or other safety features.



**Note:** The installation illustrations are for reference only. If you use the Smart Box III, the location of the fuse box may vary depending on vehicle model. It is recommended that you contact a professional installer (for example, the service personnel of the vehicle) for assistance.

- When adjusting the lens angle, make sure that the camera's view is parallel with level ground and the ground to sky ratio is close to a 50/50 split. You can check the camera's live view via the Navman MiVue Pro app ( **LIVE** ). Loosen the adjustment bolt on the camera's mount ( 1 ), tilt the camera upwards/downwards for the optimal lens angle ( 2 ), and then lock the camera by fastening the adjustment bolt ( 3 ).



MiVue Pro app > Live View

## Mounting the rear recording camera

Depending on your model, your device may support a rear recording camera (sold separately).


For more information on using the rear recording camera, please visit [www.navman.com.au](http://www.navman.com.au) or [www.navman.co.nz](http://www.navman.co.nz) for more information.

## Using a memory card

In order to record video footage, Navman dash cameras need a microSD. It is very important to use a microSD card specifically designed to be used in dash cameras. It will ensure the card will be more reliable and last longer; the wrong type of card has a greater chance of failing, even after a short period of time. Please visit [www.navman.com.au/memory-card](http://www.navman.com.au/memory-card) or [www.navman.co.nz/memory-card](http://www.navman.co.nz/memory-card) for more information on recommended SD cards.

Hold the card by the edges and gently insert it into the slot as shown in the illustration. To remove a card, gently push the top edge of the card inwards to release it and pull it out of the slot.

- The playback controls are described as follows:




- Skips to the previous/next file on the list.
- Starts or pauses video playback.
- Changes playback speed to 1/4x, 1/2x, 1x (default), 1.5x, or 2x.
- Mutes or unmutes the volume.
- Adjusts the volume level.
- Plays the video in full screen mode.
- Displays playback progress. You can click on a point along the track bar to move directly to a different location for the playback.

- During playback, you can check more driving information from the dashboard panel and the G-sensor chart that are displayed below the video playback screen.
  - On the dashboard panel, click to display the map screen.

**Note:** The map screen may not display when the computer is not connected to the Internet or when your dash cam model does not support the GPS function.

- G-sensor chart displays data in 3-axis waveform about the car's shift forward/backward (X), to the right/left (Y) and upward/downward (Z).

- The tool bar allows you to do the following:



- Selects the folder that stores the recording files.
- Previews and prints the current video image.
- Saves the selected files to the specified location on your computer.
- Captures and saves the current video image to the specified location on your computer.

- Opens the Settings Menu. The Settings items are described as follows:
  - Change Language:** Sets the display language of MiVue Manager.
  - Change Skin:** Sets the colour scheme of MiVue Manager.
  - Check for Update:** Checks for a new version of MiVue Manager (Internet access required).
  - About:** Displays the version and copyright information of MiVue Manager.
- Exports the GPS information of the selected file in the KML format to the specified location on your computer.
- Uploads the selected file to YouTube™.
- In the playlist, the “F” and “R” marks displayed on the filename indicate that the video comes with a corresponding front video (F) or rear video (R). While playing the video, the screen displays the PIP (picture-in-picture) mode. You can switch the front and rear videos by clicking .

**Note:** This feature is for selected models only.

## Safety precautions

### About the vehicle power adapter

- Use only the vehicle power adapter supplied with your device. Use of another type of the vehicle power adapter may result in malfunction and/or danger.
- It is recommended that you contact a skilled installer (for example, the service personnel of the vehicle) for Smart Box III (sold separately) installation and assistance.
- This product is intended to be supplied by a LISTED Power Unit marked with “LPS”, “Limited Power Source” and output rated + 5 V dc / 2.0 A.
- Do not use the vehicle power adapter in a high moisture environment. Never touch the vehicle power adapter when your hands or feet are wet.
- Allow adequate ventilation around the vehicle power adapter when connected to the vehicle. Do not cover the vehicle power adapter with paper or other objects that will reduce cooling. Do not use the vehicle power adapter while it is inside a carrying case.
- Connect the vehicle power adapter to a proper power source. The voltage requirements are found on the product case and/or packaging.
- Do not use the vehicle power adapter if the cord becomes damaged.
- Do not attempt to service the unit. There are no serviceable parts inside. Replace the unit if it is damaged or exposed to excess moisture.

## Caring for your device

Taking good care of your device will ensure trouble-free operation and reduce the risk of damage.

- The device may feel warm to the touch during constant recording or when the vehicle is parked under direct sunlight. This is normal operation for the device and does not affect the device’s performance.
- Keep your device away from excessive moisture and extreme temperatures.
- Do not place anything on top of your device or drop objects on your device.

## Privacy notice

### Location Information

The Navman device and software a customer uses may, by its nature and function, create, contain, receive, store, or transmit location based information that, either alone or in combination with other information, could identify a person, establish a person’s whereabouts, reveal the nature or type of places that a person visits or in which a person is interested, or identify a person’s movements, habits, and other information about a person (“Location Information”). This Location Information is used to provide location related services to customers. For this purpose, Navman™ may disclose Location Information to its related companies, service providers, and agents which may be located overseas in countries including the USA, China, Taiwan, Australia, New Zealand and the Philippines. Except as explained below in relation to country location when using connected device features, it is Navman’s policy not to collect or store Location Information, or to provide Location Information to unaffiliated third parties or persons who are not agents or service providers of Navman, without first receiving the consent of the customer (such as where the customer subscribes to, or directly or indirectly requests, location-based or similar services from Navman or a third party). Notwithstanding this clause, if, and to the extent that, a court order, subpoena, or rule of law requires that Navman disclose Location Information to a third party, Navman reserves the right to comply with such court order, subpoena, or rule of law.

### Connected Device Information

If the customer accesses the Navman connected device feature (or a similar feature), including from a website or mobile device, Navman may collect personal information about the customer through the connected device, such as the customer’s username, email address, social networking account username (if the customer chooses to connect to its social networking account), what country the customer is located in when using the device (but not other Location Information), and internet protocol address, (“Connected Device Information”). Connected Device Information may be automatically synced between the customer’s compatible and connected devices. When a customer uses the connected device feature, Location Information and dashcam recordings pass temporarily through our cloud infrastructure and to your device for the purpose of providing that service to you. However, we do not collect or store this data (except country location as explained above), even temporarily.

Navman will use this information to fulfil the customer’s requests for products and services, for communication, to offer products or services related to the customer’s location (including by providing information about local businesses onto the customer’s Navman device), interests and preferences and to assist Navman in its development of products and services. Connected Device Information may be provided to Navman’s related companies, agents and third party service providers to enable Navman to deliver programs, products, information and services and to maintain Navman’s websites, mailing lists and other services. The recipients that Connected Device Information is provided to may be located in different countries to that in which the customer is based, including in the USA, China, Taiwan, Australia, New Zealand and the Philippines. The third parties that data is provided to may include social media providers if the customer has linked the connected device feature to a social media account. Connected Device Information will not be transferred to third parties that are not acting on behalf of Navman without the customer’s consent unless required by law or for the purposes disclosed in this clause. The customer may choose not to provide Connected Device Information to Navman, but this may cause certain features of the connected device to be unavailable.

### Information Storage

Any Location Information or Connected Device Information will be collected and held by CloudMade Inc., 1370 Willow Road, Menlo Park, CA 94025, USA (a third party company which provides cloud services to us), MiTAC Australia Pty Ltd, Unit 5, 43-51 College Street, Gladesville, NSW 2111, Australia. Navman will take reasonable steps to secure any Location Information or Connected Device Information about the customer.

### Access, correction and complaints

The customer may request to see a copy of the Location Information or Connected Device Information held by Navman about the customer, and can request corrections to be made to the Location Information or Connected Device Information. Navman’s privacy policy contains information about how a customer may exercise their rights under the foregoing sentence, how a customer may complain about any breach of privacy laws or applicable codes, and how Navman will deal with such a complaint.

- Do not drop your device or subject it to severe shock.
- Do not subject your device to sudden and severe temperature changes. This could cause moisture condensation inside the unit, which could damage your device. In the event of moisture condensation, allow the device to dry out completely before use.
- Never clean your device with it powered on. Use a soft, lint-free cloth to wipe the exterior of your device.
- Never attempt to disassemble, repair or make any modifications to your device. Disassembly, modification or any attempt at repair could cause product damage, bodily injury, or property damage and will void any warranty.
- Do not store or carry flammable liquids, gases or explosive materials in the same compartment as your device, its parts or accessories.
- To discourage theft, do not leave the device and accessories in plain view in an unattended vehicle.
- Overheating may damage the device.

## About the battery

**CAUTION!** This unit contains a non-replaceable internal Lithium Ion battery. The battery can burst or explode, releasing hazardous chemicals. To reduce the risk of fire or burns, do not disassemble, crush, puncture, or dispose of in fire or water.

Caution! Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

- Replace only with the same or equivalent type recommended by the manufacturer.
- The battery must be recycled or disposed of properly.
- Use the battery only in the specified equipment.
- Battery clause safety information.

Your product uses a Lithium-ion battery. It is important to follow the guidelines set out regarding this type of Battery. Electronic devices using a lithium – ion battery such as Mobile phones, GPSs and cameras are designed to operate at a temperature range of approximately 0°C to 50°C. Beyond these temperature limits, there may be a risk of battery failure, when these electronic goods are exposed to extreme heat conditions for long periods.

It is recommended that you do not use your device in a humid, wet and/or corrosive environment. Do not put, store or leave your device in or near a heat source, in a high temperature location, in strong direct sunlight and do not expose it to temperatures over 60°C (140°F). Failure to follow these guidelines may cause the Lithium-ion battery to leak acid, become hot, explode or ignite and cause injury and/or damage. Do not pierce, open or disassemble the battery. If the battery leaks and you come into contact with the leaked fluids, rinse thoroughly with water and seek medical attention immediately. For safety reasons, and to prolong the lifetime of the battery, charging should not occur at low (below 0°C/32°F) or high (over 45°C/113°F) temperatures.

THE LITHIUM-ION BATTERY CONTAINED IN THE PRODUCT MUST BE RECYCLED OR DISPOSED OF PROPERLY. IT IS HIGHLY RECOMMENDED YOU USE YOUR PRODUCT ONLY WITH THE SUPPLIED DC POWER LEAD (VEHICLE POWER ADAPTER/ BATTERY CABLE) AND AC ADAPTER (HOME CHARGER) FOR BATTERY CHARGING.

For more information on how to recycle your old electronic devices, please contact your local council office. You can also visit [www.navman.com.au/](http://www.navman.com.au/) [www.navman.co.nz/](http://www.navman.co.nz/) to view our latest trade-in offers.

Navman’s privacy policy is available at <https://www.navman.com.au/privacy>.

\* In this Privacy Notice, the term “Navman” means MiTAC Australia Pty Ltd (an entity registered in Australia and New Zealand and trading as Mitac Professional Solutions, Magellan GPS Technology, MIO TECHNOLOGY and NAVMAN TECHNOLOGY.

## Two-year limited warranty

The two-year limited warranty applies separately to your use of the product, and should be read independently of the other terms contained in the user manual.

### 1. Scope.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law and the New Zealand Consumer Guarantees Act 1993. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Where a product is comprised of both hardware and software and a separate software licence is provided with the product, the terms of the software licence apply to the software and this limited warranty applies only to the hardware portion of the product. This section does affect any rights you may have under the Consumer Guarantees (as defined below).

This warranty is given by MiTAC Australia Pty Ltd (“Navman”), in Australia and New Zealand.

### 2. Warranty.

Apart from any rights that you may have because of the Consumer Guarantees (as defined below), Navman warrants to the original end-user retail purchaser from an authorized Navman dealer that this product will be free from defects in material and workmanship and (where a User Manual is provided) will substantially conform to the specifications and descriptions in the User Manual for the Warranty Period. The “Warranty Period” is two years from the date of original retail purchase in Australia and New Zealand, as supported by a complete, legible and dated copy of the original sales receipt.

### 3. Exclusions and Limitations.

This section sets out exclusions and limitations which apply to the warranty. It does not affect the rights of any person under the Consumer Guarantees (as defined below). This warranty does not cover any non-rechargeable batteries, finishes, service performed or attempted by anyone other than an authorised Navman Service Centre, installations or defects caused by improper installation, any products, components or parts not manufactured by Navman, any claim in relation to infringement of any patent, trademark, copyright or other proprietary right, including trade secrets, any damage or failure of the product caused by shipping, misuse, tampering, abuse, negligence, wear and tear in excess of that expected from normal consumer use, unauthorised attachments or modification, failure to maintain as recommended, electrical discharges (including lightning), exposure to water (except as otherwise stated in the User Manual), moisture or liquids, proximity or exposure to heat, disasters such as fire, flood, wind, and lightning, or failure of availability or reliability of any external resource necessary or useful for the product’s operation (for example, and to the extent applicable, the global positioning system constellation of satellites and their transmissions; traffic, weather, navigation, point-of-interest, or other data; and radio-frequency or other wired or wireless signals, whether transferring data or otherwise). Improper or incorrectly performed maintenance or repair, commercial use, or alteration or removal of any serial number or the opening, dismantling or repair of this product by anyone other than an authorised Navman Service Centre each will void this warranty. To the extent that the product is used or useful for navigation: (a) the product, including any associated electronic charts or maps, navigation data, or radio or other services, is a supplement to other navigational resources and not a replacement of them; (b) the product does not replace any charts, maps, or other information required by law to be used for any activity (such as nautical or aeronautical charts); (c) errors and omissions are inevitable; (d) the user is responsible for cross-checking the product against other sources of navigation information; and (e) Navman recommends having back-up navigation tools available in the event that the product becomes inoperable.

## About GPS

- GPS is operated by the United States government, which is solely responsible for the performance of GPS. Any change to the GPS system can affect the accuracy of all GPS equipment.
- GPS satellite signals cannot pass through solid materials (except glass). When you are inside a tunnel or building, GPS positioning is not available. Signal reception can be affected by situations such as bad weather or dense overhead obstacles (e.g. trees, tunnels, viaducts and tall buildings).
- The GPS positioning data is for reference only.

## Important notice

In addition to the user manual, this document contains the following terms that apply to your use of your Navman product:

- Software licence;
- Privacy notice; and
- Two-year limited warranty.

## Software licence

### 1. Generally.

Navman (“Licensor”) is willing to grant the following licence (the “Licence”) to use the software, if any, provided with this Software Licence and Privacy Notice (whether provided separately or associated with a device) (the “Licensed Product”) to the original retail purchaser (and, subject to the limitations below, certain transferees) of the Licensed Product or the device upon or with which the Licensed Product was installed or associated as of the time of purchase (the “Customer”) only if Customer accepts all of the terms of the Licence.

PLEASE READ THESE TERMS CAREFULLY. USING THE SOFTWARE WILL CONSTITUTE CUSTOMER’S ACCEPTANCE OF THE TERMS AND CONDITIONS OF THIS LICENCE. PLEASE NOTE THAT THIS LICENCE IS NOT ITSELF A LICENCE TO USE NAVIGATION DATA THAT MAY BE INCLUDED WITH A DEVICE. NAVIGATION DATA IS COVERED BY A SEPARATE LICENCE AGREEMENT. IF YOU DO NOT AGREE TO THE TERMS OF THIS LICENCE, DO NOT INSTALL OR USE THE LICENSED PRODUCT. RATHER, RETURN THE LICENSED PRODUCT (AND, IF YOU RECEIVED THE LICENSED PRODUCT INSTALLED ON A DEVICE, RETURN THE DEVICE) PROMPTLY, INCLUDING ALL PACKAGING AND WRITTEN MATERIALS, TO LICENSOR AND LICENSOR WILL REFUND TO CUSTOMER THE ORIGINAL RETAIL PRICE PAID FOR THE PRODUCT (LESS DELIVERY AND HANDLING CHARGES, WHERE PERMITTED).

### 2. Licence Grant.

This section does not limit or affect the rights of any person under the Consumer Guarantees (as defined in section 7).

Licensor grants to Customer a non-exclusive licence (without right to transfer, assign, or sublicense except as stated in this Licence) to use: (a) the Licensed Product (that term being further restricted where the Licensed Product is, or contains, a work of authorship fixed in tangible (including electronic) media to mean the single purchased copy thereof); and (b) the accompanying materials, including any manuals contained in the Licensed Product (the “Materials”), in accordance with the terms and conditions of this Licence.

### 3. Limitations on Use.

Customer will not place, secure, or use, or permit any other person to place, secure, or use, the Licensed Product or any device associated with the Licensed Product, in a manner that limits any user or operator’s view, that is likely to distract any user or operator, or that may cause accidents, personal injury, or property damage. Customer, and any user that Customer permits to use the Licensed Product or any associated device, is solely responsible for observing safe driving, operating, and other practices so as to avoid accidents or injury to persons or property. Certain functionality of the Licensed Product or the

## 4. Remedies and How to Obtain Warranty Service.

If the product is defective or fails to conform with the warranted specifications, and you send the product and all other required information and materials to Navman, or return it to the retail outlet from which it was purchased, on or before the last day of the Warranty Period (refer to the process at 1 to 3 below), Navman will repair or replace (at Navman’s option) the product. This is your remedy for defective or non-conforming products under Navman’s warranty. You may have other rights or remedies under applicable laws (including under the Consumer Guarantees, as defined below).

To obtain your warranty service:

- Contact Navman to obtain a Return Materials Authorization number (RMA). You can reach Navman using the Contact Details outlined at 3 below or through your authorized Navman dealer.
- Pack the product, a copy of your dated purchase receipt, your address and telephone number, and any other information Navman requests as part of the return authorization process (such as any return authorization form you receive) in sturdy packing material.
- Ship the product and the other required items to Navman at the address specified in the Contact Details below, or return it to the retail outlet from which it was purchased, on or up to the end of the Warranty Period. You should retain proof of shipping to evidence the date of shipment. Please send the item by registered post for tracking purposes.

Contact Details:

In Australia:	In New Zealand:
Attention: Navman Repairs	New Zealand Couriers INTL
RMA No. .... (Required)	Navman Repairs
Locked bag 5010	RMA No. .... (Required)
Gladesville NSW 1675	32 Botha Rd
Phone: 1300 628 626	Penrose, Auckland
Email: <a href="mailto:pcnsupportaus@navman.com.au">pcnsupportaus@navman.com.au</a>	Phone: 0800 466 286
	Email: <a href="mailto:pcnsupportaus@navman.com.au">pcnsupportaus@navman.com.au</a>

Please provide the following information when returning your product:

Sender’s name: .....  
 Sender’s address: .....  
 Sender’s phone: .....  
 Sender’s email: .....

RMA number (compulsory - please call the support number above for your RMA number).

If an RMA is not obtained before sending the unit in for repair, the unit will be quarantined and this will add to the repair turnaround time by at least one week.

You must pay for shipping and any insurance to get the product to Navman at the applicable address. Except where otherwise provided by Consumer Guarantees (as defined below), you assume all risk of loss or damage to the product until it arrives at Navman’s facility. Navman will pay for ground shipping of the new or repaired product back to you at an address in the same country as the repair facility and assume all risk of loss or damage to the product until it arrives at the address you specify. You must request, and pay for, any different shipping method. The repair of the product may result in loss of data. Navman will not be responsible for the loss or alteration of any user data stored in the product. You should back up or otherwise preserve any such data before sending the product to Navman. Except where otherwise required by Consumer Guarantees (as defined below in this document), if Navman reasonably determines that the product has not failed to meet the standards of the warranty, you will be liable for the cost of return shipment to you, Navman may require payment of such costs before returning the product to you, and the risk of loss or damage will remain with you notwithstanding Navman’s possession of the product. The Warranty Period will stop running on the day you send the product to Navman. The remainder of the Warranty Period will begin to run again when the repaired or replacement product arrives at the address you specify.

device may be dependent upon the use of hardware (sometimes called a “dongle” or “module”) or software keys that enable or unlock the functionality. This Licence does not permit Customer to use any of such functionality unless Customer has also legitimately bought or otherwise obtained the appropriate dongle, module, or software key. Each dongle, module, or software key is intended solely to enable the portion of functionality of the Licensed Product or device described in the documentation associated with the dongle, module, or software key and no other functionality.

## 4. Intellectual Property Rights.

As between Licensor and Customer, the copyright and all other intellectual property rights in the Licensed Product and Materials (including any enhancements or modifications) are the property of Licensor. Customer must not rent, lease, reproduce, translate, adapt, vary, reverse-engineer, or modify the Licensed Product or Materials or communicate the same to any person other than in accordance with the terms of this Licence (or to the extent permitted by mandatory laws). Customer may not rent or lend the Licensed Product, or reproduce, prepare any derivative work, distribute, perform publicly, display publicly, perform by digital or other transmission, or broadcast the Licensed Product. Any rights not expressly granted in this Licence are reserved by Licensor.

## 5. Transfer of Licence.

Customer may transfer this Licence to a subsequent transferee of the Licensed Product or the device, if any, upon which the Licensed Product is installed, provided that Customer transfers to the transferee all physical embodiments of the Licensed Product, the device upon which the Licensed Product is installed, if any, and all of the Materials, and retains no copy or part of the Licensed Product or the Materials.

Where the Licensed Product is transferred, technical support offered by the Licensor will only be available to the transferee, if the transferee provides proof of the original purchase of the Licensed Product.

## 6. Copying.

Customer may not copy the Licensed Product or Materials except that one copy of any separate software component of the Licensed Product may be made to the extent that such copying is necessary for Customer’s own backup purposes.

## 7. Liability.

7.1 Interpretation - Consumer Guarantees.

In this Software Licence and Privacy Notice:

- “Australian Consumer Law” has the meaning given to that term in section 4 of the Competition and Consumer Act 2010 (Commonwealth of Australia);
- “Consumer” has the meaning given to that term in section 3 of the Australian Consumer Law, or section 2 of the New Zealand Consumer Guarantees Act 1993, as the context requires;
- “Consumer Guarantees” has the meaning given in section 7.2 below; and
- “PDH Goods or Services” means goods or services of a kind ordinarily acquired for personal, domestic or household use or consumption.

7.2 Consumer Guarantees

Under the Australian Consumer Law (and other similar legislation of Australian states and territories) and the New Zealand Consumer Guarantees Act 1993, certain statutory guarantees are conferred in relation to the supply of goods or services to a Consumer (“Consumer Guarantees”).

7.3 Limitation of Liability – Consumer Guarantees.

Where you as a Consumer acquire goods and services under this Licence from Licensor:

## 5. Applicable Law.

Where the product was acquired by the original retail purchaser in Australia, this limited warranty is governed by the laws of New South Wales. Where the product was acquired by the original retail purchaser in New Zealand, this limited warranty is governed by the laws of New Zealand.

## 6. Consumer Guarantees

6.1 Interpretation.

In this two-year limited warranty:

- “Australian Consumer Law” has the meaning given to that term in section 4 of the Competition and Consumer Act 2010 (Commonwealth of Australia);
- “Consumer” has the meaning given to that term in section 3 of the Australian Consumer Law, or section 2 of the New Zealand Consumer Guarantees Act 1993, as the context requires;
- “Consumer Guarantees” has the meaning given below; and
- “PDH Goods or Services” means goods or services of a kind ordinarily acquired for personal, domestic or household use or consumption.

6.2 Consumer Guarantees

Under the Australian Consumer Law (and other similar legislation of Australian states and territories) and the New Zealand Consumer Guarantees Act 1993, certain statutory guarantees are conferred in relation to the supply of goods or services to a Consumer (Consumer Guarantees).

In addition to the warranty, you may also have other rights under the Consumer Guarantees which cannot be excluded, restricted or modified by agreement. This warranty does not exclude, restrict or modify the application of any condition, warranty, guarantee, right or remedy conferred by or implied under any provision of any statute where to do so would: (a) contravene that statute or (b) cause any part of this clause to be void.

Where you as a Consumer acquire goods and services to which this warranty relates:

- subject to clause 6.3, in Australia or New Zealand, where the goods or services are PDH Goods or Services, the operation of the applicable Consumer Guarantees cannot be, and are not in this Licence, excluded, restricted or modified; or
- in Australia (or if Consumer Guarantees are otherwise conferred in relation to those goods and services by Australian law), where the goods or services are not PDH Goods or Services, Navman limits its liability for a failure to comply with any Consumer Guarantee (other than where to do so would otherwise cause all or part of this clause to be void) to (at Navman’s option): (i) in the case of goods, repairing or replacing the goods or paying the cost of having the goods repaired or replaced; and (ii) in the case of services, re-supplying the services or paying the cost of having the services re-supplied, and Navman does not exclude or limit the operation of the Consumer Guarantees under any other provision of this warranty or in any other manner and you agree it is fair and reasonable in all the circumstances for Navman’s liability to be so limited.

6.3 Business Supplies in New Zealand

In New Zealand, where both Navman and you are ‘in trade’ and you are acquiring the goods and services for the purposes of a business, then both Navman and you acknowledge and agree that the statutory guarantees and implied terms, covenants and conditions contained in the New Zealand Consumer Guarantees Act 1993 are excluded to the fullest extent permitted by law and do not apply, and Navman does not exclude or limit the operation of the Consumer Guarantees under any other provision of this warranty or in any other manner and you agree it is fair and reasonable in all the circumstances for Navman’s liability to be so limited.

## 7. Disclaimers and Other Provisions

To the extent permitted by law and except for the Consumer Guarantees and the warranty described above, Navman excludes all representations, guarantees, conditions, warranties rights and remedies, liabilities and other terms that may be conferred or implied by statute, general law or custom, in fact or otherwise, except any guarantee, implied term or right conferred under any legislation (including the Australian Consumer Law and the New Zealand Consumer Guarantees Act 1993), the exclusion of which would contravene legislation or cause part or all of this clause to be void and the customer acknowledges that Navman does not warrant that the operation of the product will be continuous or error-free.

(a) subject to clause 7.4, in Australia or New Zealand, where the goods or services are PDH Goods or Services, the operation of the applicable Consumer Guarantees cannot be, and are not in this Licence, excluded, restricted or modified; or

(b) in Australia (or if Consumer Guarantees are otherwise conferred in relation to goods and services by Australian law), where the goods or services are not PDH Goods or Services, Licensor limits its liability for a failure to comply with any Consumer Guarantee (other than where to do so would otherwise cause all or part of this clause to be void) to (at Licensor’s option): (i) in the case of goods, repairing or replacing the goods or paying the cost of having the goods repaired or replaced; and (ii) in the case of services, re-supplying the services or paying the cost of having the services re-supplied, and Licensor does not exclude or limit the operation of the Consumer Guarantees under any other provision of this Licence or in any other manner and you agree it is fair and reasonable in all the circumstances for Licensor’s liability to be so limited.

To the extent permitted by law and except for the Consumer Guarantees, Licensor excludes from this Licence all representations, guarantees, conditions, warranties, rights, remedies, liabilities and other terms that may be conferred or implied by statute, general law or custom, in fact or otherwise, except any guarantee, implied term or right conferred under any legislation (including the Australian Consumer Law and the New Zealand Consumer Guarantees Act 1993), the exclusion of which would contravene legislation or cause part or all of this clause to be void.

7.4 Business Supplies in New Zealand

In New Zealand, where both Licensor and Customer are ‘in trade’ and Customer is acquiring the goods and services for the purposes of a business, then both Licensor and Customer acknowledge and agree that the statutory guarantees and implied terms, covenants and conditions contained in the New Zealand Consumer Guarantees Act 1993 are excluded to the fullest extent permitted by law and do not apply, and Licensor does not exclude or limit the operation of the Consumer Guarantees under any other provision of this Licence or in any other manner and you agree it is fair and reasonable in all the circumstances for Licensor’s liability to be so limited.

7.5 Limitation of Liability – General.

To the extent permitted by law and except for any liability under the Consumer Guarantees: (a) the Licensor will not, under any circumstances, be liable under the law of tort, contract, or otherwise for any loss of profits or loss of data or any indirect or consequential loss or damage, however caused, arising out of or in connection with this Licence; (b) the Licensor’s aggregate liability for all claims arising out of or in connection with this Licence will be limited to the total amount actually and originally paid at retail by the customer for the Licensed Product; and (c) without limiting the foregoing or any other limitation of liability or disclaimer contained in this Software Licence and Privacy Notice, all limitations and disclaimers contained in the product warranty or any limited warranty for any product sold in connection with the Licensed Product also apply to this Licence.

## 8. Termination.

Licensor may, in addition to any other remedies available to Licensor, terminate this Licence immediately if Customer breaches any of its obligations under this Licence.

## 9. Product warranty.

The warranty for the Licensed Product is set out in the warranty documentation provided with the Licensed Product or the device on which the Licensed Product is installed (subject to any exclusions and limitations set out in this document), and applies in addition to this Licence and to any rights that you have under the Consumer Guarantees.

## 10. Governing Law and interpretation.

Where the Licensed Product was acquired by the original retail purchaser in Australia, this Licence is governed by the laws of New South Wales, the parties submit to the non-exclusive jurisdiction of the courts of New South Wales. Where the Licensed Product was acquired by the original retail purchaser in New Zealand, this Licence is governed by the laws of New Zealand, the parties submit to the non-exclusive jurisdiction of the courts of New Zealand. The term “Navman” refers to MiTAC Australia Pty Ltd of Unit 5, 43-51 College Street, Gladesville, NSW 2111, Australia.

Except for liability for a breach of a Consumer Guarantee (a) Navman will not, under any circumstances, be liable under the law of tort (including negligence), contract, or otherwise for any loss of profits or loss of data or any indirect or consequential loss or damage, however caused, arising out of or in connection with the product; (b) Navman’s aggregate liability for all claims arising out of or in connection with the product will be limited to the total amount actually and originally paid at retail by the customer for the product.

## 8. Privacy Notice

We collect the personal information you provide when you obtain this warranty and if you make a warranty claim to provide the warranty and any warranty service. We collect this information either directly from you or from the agent which handles our warranty claims.

We may disclose your personal information to: (i) the agent which handles our warranty claims; (ii) our related companies, our employees and agents; (iii) anyone required or authorised by law; and (iv) anyone else you authorise. These recipients may be located overseas including in Australia, New Zealand, Taiwan, the USA, China and the Philippines.

Our policy on the collection, use and disclosure of your personal information is set out in our Privacy Policy available at <https://www.navman.com.au/privacy>. Our policy contains details about how to access or correct the personal information we hold and how to complain about a privacy breach and how we will handle such a complaint.

## 9. Disclaimer

In the event of improvements to the product, and software, or in limited circumstances where events occur outside Navman’s control, specifications and documents may be subject to change without notice. While Navman has taken reasonable care to ensure the accuracy of this document, due to circumstances outside of Navman’s control, Navman cannot warrant this document is at all times error-free.

## 10. Notes

Not all models are available in all regions. Depending upon the specific model purchased, the colour and look of your device and accessories may not exactly match the graphics shown in this document. Screenshots and other presentations shown in this document are for reference only. They may differ from the actual screens and presentations generated by the actual product.